

# USER'S MANUAL

## PENDANT ITEM# 4531-3H

### WARNING

1. Shut off the power to the area where you will be working.
2. Use 60 watt maximum type A bulb.
3. Do not use polish or cleaner on your lamp, just wipe with soft cloth.

### STEP 1 -- UNPACK

1. Carefully unpack your new fixture and lay out all the parts on a clear surface.
2. The bag includes a mounting pack.

### STEP 2 --PENDANT ASSEMBLY

1. Screw the NIPPLE (29) into the METAL RING (40) with HEX NUT(30), attach the POLY (28) (25) to it .
2. Screw the TUBE(24) to the NIPPLE(29), attach the COVER(23) and the TUBE(22) to it and screw them.
3. Screw the NIPPLE(19) into the TUBE(22) with the HEX NUT(20), and then put the ARM(26) to the TUBE(22) and the METAL RING(40) screwed with the BALL NUT(21)(27) respectively.
4. Screw the HEX NUT(18) to NIPPLE(19),then attach the COVER(17), HEX NUT(16) to it and screw with the LOOP(15).
5. Screw the NIPPLE(33) to the HEX CONNECTOR(31) with the HEX NUT(32),attach the GLASS SHADE(34),PLASTIC WASHER(35), METAL WASHER(36),HEX NUT(37), COVER(38),FINIAL(39) to it and screw them.

### STEP 3 –FIX WIRE INSTALLATION

✂ We advise contacting a qualified electrician for this step.

6. Thread the NIPPLE(9) into the LOOP(11) until snug.
7. Screw the other end of NIPPLE(9) to the CROSS BAR(6) with the WASHER(4) and HEX NUT(5).
8. Take this crossbar assembly and mount to ceiling junction box with JUNCTION BOX SCREWS(7), Tighten thread securely with screwdriver.
9. Lace the fixture wires through the chain. CANOPY(10) over the chain.
10. Cut the wire plug off, Feed the fixture wires through the LOOP(15) and NIPPLE(9) and pull until taut.
11. Connect fixture wire to the wire from junction box with wire connectors, See paragraph below.
12. Push CANOPY(10) up against ceiling and secure with COLLAR NUT(12).

### ✂ WIRE CONNECTION

FOR WIRE CONNECTION, BE SURE TO CONNECT, FIXTURE SMOOTH WIRE TO THE BLACK HOUSE WIRE, RIBBED WIRE TO THE WHITE HOUSE WIRE AND FIXTURE GROUND WIRE TO SUPPLY GROUND WIRE WITH WIRE CONNECTORS OR THE FIXTURE GROUND WIRE FROM THE FIXTURE TO THE GREEN GROUND SCREW ON THE MOUNTING BRACKET.

✂ Your installation is now complete. Turn power on.

